



Detectable Silicone Rubber Ear Plug

2 Flange (SNR 24) Code DTM 0205

3 Flange (SNR 25) Code DTM 0201

(SNR rating in excess of 20 gives adequate protection for most factory environments).



Image DTM 0201

Designed for maximum user comfort meeting the requirements of EN352-2 and CE-Marked in accordance with European Directive 89/686/EEC.

Fitting

It is important your hands are clean before handling the plugs.

Place one hand across the top of your head and slightly raise the opposite outer ear (pinna), this will open the ear canal to allow the plug to be inserted (the plugs should be inserted as deep as possible) holding your mouth open will help with insertion.



Removal

Always remove slowly with a slight twisting action.

Hygiene

To prevent cross contamination, it is recommended to tie a knot at one end of the cord to designate its use in a specific ear. The protectors can also be supplied with a blue plug one end, red the other for identification.

Cleaning

After use the plugs can be washed in mild detergent and should be thoroughly dried before re-use.

Remember: Keep it clean – Stop infection.

Tel: 0044 (0)1759 304 200 www.detectamet.com